


## Advanced Mule Pattern - Square



**Aim:** To show that the mule is focused and responsive to the handler. The lead should be held no closer than 30cm from the clip end and hang relaxed throughout.

**Dimensions – 20m X 20m minimum**

1. Halt at cone 1. Proceed at Walk to 2nd cone.
2. At the 2nd cone proceed across the diagonal showing three clear variations in speed (slow-quick-slow)
3. Go around cone 4 and proceed into trot to cone 3.
4. Trot around cone 3 proceeding across the diagonal.
5. When halfway across Halt, Reverse 5 strides, and proceed at a Trot.
6. Trot around cone 1 and cone 2 and up to cone 3.
7. At cone 3 Halt for 4 seconds.
8. Complete a 180° turn around the hindquarters then proceed at Walk.
11. Go around cone 2 and proceed into trot to cone 1.
12. Halt at cone 1.